


Item Sales			Item Sales			Item Sales		
No.	No.	Description	No.	No.	Description	No.	No.	Description
1	HMN 386	Dome Nut M9	9	HSB 534	XL-FD Hub Shell	15	HSK 715	Pinch Bolt
2	HMW 528	Safety Washer	10	HSB 396	Replacement Axle Unit	16	HSL 702	Brake Arm Clip 17.5mm
3	HMN 377	Locknut M9, t=4.7, hex 17			includes hub bearings and		HSL 703	Brake Arm Clip 22.2mm
4	HMW 129	Spacing Washer 1/8"			items 1, 3, 4, 5, 7, 11, 12	17	HSK 742	Brake Lever BLS80 RH
5	HSA 372	Brake Plate Spacer	11	HSA 398	Spacer 4.7mm		HSK 743	Brake Lever BLS80 LH
6	HSB 525	90mm Alloy Front Brake Plate Assy.	12	HSA 376	Spacer 3.2mm			
7	HSA 373	Brake Plate Bush	13	HSK 730	Brake Cable Complete 900mm			
8	HSS 034	Bearing 6000ZZ	14	HSB 422	Brake Adjuster Assy.			



Item Sales			Item Sales			Item Sales		
No.	No.	Description	No.	No.	Description	No.	No.	Description
1	HMN 386	Dome Nut M9	9	HSB 523	2.4W XL-FDD Hub Shell Assy.	15	HSL 702	Brake Arm Clip 17.5mm
2	HMW 528	Safety Washer			w/Magnet and Bearing		HSL 703	Brake Arm Clip 22.2mm
3	HMW 527	Toothed Lock Washer 3/8"		HSB 524	3.0W XL-FDD Hub Shell Assy.	16	HSK 730	Brake Cable Complete 900mm
4	HSX 146	2.4W Dynohub Internal			w/Magnet and Bearing	17	HSB 422	Brake Adjuster Assy.
	HSX 147	3.0W Dynohub Internal	10	HSS 035	Bearing 6000UU	18	HSK 715	Pinch Bolt
5	HMN 377	Locknut M9, t=4.7, hex 17	11	HSA 373	Brake Plate Bush	19	HSK 742	Brake Lever BLS80 RH
6	HSE 001	Connector Assy.	12	HSB 525	90mm Alloy Front Brake Plate Assy.		HSK 743	Brake Lever BLS80 LH
7	HSE 002	Plug for Connector	13	HSA 372	Brake Plate Spacer	20	HTR 139	Spanner for Side Cap
8	HSS 036	Bearing 629UU	14	HMW 146	Washer 1/16"			